Brittany Disappearing Desk Bed



The following instruction and hardware list will help you identify hardware needed and where to find it as you watch the Disappearing Desk Bed installation video.

Installation video link:

https://www.wallbedsbywilding.com/disappearing-installation/

Or

View DVD provided with this packet

The following hardware list will help you identify hardware needed and where to find it as you watch the Disappearing Desk Bed installation video.

Installation video link:

https://www.wallbedsbywilding.com/disappearing-installation/

	Hardware from Manila Envelope			Hardware from box labelled: HiddenBed
Video Step 1	Hardware found in bag #1	Connecting Bolt	18	No hardware needed
Video Step 2	No hardware needed			No hardware needed
Video Step 3	No hardware needed			No hardware needed
Video Step 4	No hardware needed			No hardware needed
Video Step 5	Hardware found in bag #1	Connecting Bolt	6	No hardware needed
Video Step 6	Hardware found in bag #6	Square Tip Bit  3 1/2" Wood Screw 1/4" Drill Bit	1 3 1	No hardware needed
Video Step 7	Hardware found in bag #7	3/16" Machine Screw 3/16" Barrel Nut 1/4" x 40mm 1/4" Barrel Nut	16 16 4 4	Hardware found in HiddenBed Box  2  2 2 2 
Video Step 8	Hardware found in bag #8	1/4" x 45mm 1/4" x 20mm 4mm Allen wrench	2 4 1	Hardware found in HiddenBed Box  4 8  2 4

	Hardware from Manila Envelope			Hardware from box labelled: HiddenBed
Video Step 9	Hardware found in bag #9	 2 1/2" BLACK Wood Screw	4	4 2
		 Black Finish Washer	4	
		 8mm wood dowel	8	
	Hardware found in bag #1	 Connecting Bolt	4	
Video Step 10	Hardware found in bag #10	 1 1/4" Pocket Hole Screw	60	No hardware needed
		 1 1/4" Wood Screw	26	
		 1 1/4" Phillips washer head wood screw	4	
		 Elastic Straps	2	
Optional Twin Size Bed Addendum This Step only applies if your bed is a twin size.	Hardware found in bag # T	 Small "L" Bracket	2	No hardware needed
		 5/8" Pan head Screw	4	

	Hardware from Manila Envelope			Hardware from box labelled: HiddenBed	
Video Step 11	Hardware found in bag #11	 10mm Allen wrench	1	 	2 2 2
Video Step 12	No hardware needed			 	2 4
Video Step 13	Hardware found in bag #13	 Handle 1” Machine screw	2 4	No hardware needed	
(Bag Label) Extra	Extra Hardware	 Cam Fitting	4		